



ISO 9001
Certified

...Innovative liquid vaporizing and gas mixing solutions

Direct Fired

LP-Gas Vaporizer: 40/40H, 60/60H, 80/40H, & 120/60H

Operations & Maintenance Manual

1140 NW 46 Street, Seattle, Washington, USA 98107

Tel: 206-789-5410 Fax: 206-789-5414 Web: www.algas-sdi.com

This manual covers units built after July 2004

After S/N:

40/40H – A04G0015750

60/60H – A04G0000001

80/40H – A04G0034700

120/60H – A04G0000001



WARNING

Read the OPERATION MANUAL before operating this equipment.

- **NOTE:** Algas-SDI reserves the right to use alternate manufacturers' components as vendor delivery applicability dictates. Literature contained in the Operation Manual has been supplied by vendors. Please check to be sure supplied data matches your configuration. Contact Algas-SDI if any questions exist.
- This equipment uses LPG-a flammable fuel, handled under pressure. Inherent hazards exist and a thorough understanding of the equipment is required to allow safe operation and maintenance.
- Allow only a TRAINED and FULLY QUALIFIED PERSON to service this equipment.
- Any time a component must be replaced, use the same type, model, etc. DO NOT SUBSTITUTE! The consequence from such actions are unpredictable and may lead to dire consequences. When components are replaced with components not approved for use in our UL listed equipment, the UL listing becomes void for that unit.

Warranty, Copyrights and Approvals

WARRANTY

Algas-SDI International, LLC (ASDI) warrants that the equipment is free of defects in materials and workmanship under normal use and service. ASDI agrees to repair or replace, at our option, without charge f.o.b. factory, any part which has proven defective to the satisfaction of Algas-SDI International, LLC within one (1) year from the date of the original installation or within 18 months from the date of shipment, whichever is earlier. Equipment, which in the opinion of ASDI, has been damaged by improper installation or operation, or has been abused or tampered with in any way, will not be accepted for return under warranty.

Algas-SDI International, LLC will not accept back charges for work performed by others upon or in conjunction with ASDI equipment, unless prior authorization is given by means of an Algas-SDI International, LLC purchase order. Algas-SDI International, LLC will not be liable by reason of shutdown, non-operation or increased expense of operation of other equipment, or any other loss or damage of any nature, whether direct or consequential, arising from any cause whatsoever.

Algas-SDI International, LLC makes NO other warranty of any kind, whatsoever expressed or implied; and all warranties of merchantability and fitness for a particular purpose are hereby disclaimed by Algas-SDI International, LLC and excluded from these terms of sale. No person has any authority to bind Algas-SDI International, LLC to any representation or warranty other than this warranty.

COPYRIGHT

Copyright 2000 by Algas-SDI International, LLC, Seattle, Washington 98107. All rights reserved. No part of this manual may be reproduced or copied in any form or by any means, photographic, electronic, or mechanical, without the prior express written consent from Algas-SDI International, LLC, Seattle, Washington, USA.

APPROVALS



This page left intentionally blank

IMPORTANT WARRANTY NOTICE:


The Algas-SDI warranty period for equipment is 18 months after shipment from our facility or 12 months after installation. See our warranty statement at the beginning of this manual for the complete text. A warranty registration card has been provided with this manual so that you may register the date of installation for warranty purposes. If you do not return the warranty registration card, the warranty term will be 12 months after the equipment has been shipped to you, the end user. If you do not install it immediately, your warranty may expire earlier than necessary. The warranty registration also gives us information to contact you if we need to send you important information about the equipment later on.

Please register your equipment.

Symbols and Conventions

Special symbols are used to denote hazardous or important information. You should familiarize yourself with their meaning and take special notice of the indicated information.

Please read the following explanations thoroughly.



GENERAL WARNING OR CAUTION

Indicates hazards or unsafe practices which can result in damage to the equipment or cause personal injury. Use care and follow the instructions given.



FLAMMABLE GAS HAZARD

Indicates a potential hazard which can result in severe personal injury or death. Use extreme care and follow the instructions given.



ELECTRICAL DISCONNECT REQUIRED

Indicates a potentially dangerous situation which can result in severe personal injury or death or damage to equipment. Use great care and follow the instruction given.

PARTS AND PRICES

For parts and prices contact your Algas-SDI distributor or check our web site to locate your authorized distributor.

Internet: <http://www.algas-sdi.com>

ASDI CONTACT NUMBERS

If you have questions, need help with your equipment, or want information on other products, contact your distributor or Algas-SDI at:

Telephone: 206.789.5410

Facsimile: 206.789.5414

Email: sales@algas-sdi.com

Internet: <http://www.algas-sdi.com>

Table of Contents

Options

Auto Re-igniter
Contaminant Separator / Filtaire
Economy Kit
Inlet and Outlet Hand Valves
Pipeaway Adapter
1st Stage Regulator

1. Introduction

Description/Overview	1-1
How The Vaporizer Works	1-1
Direct Fired System Basic Features	1-2
<i>Figure 1 – Direct Fired Vaporizer - System Basic Features</i>	1-2

2. Installation

General	2-4
Unpacking and Initial Assembly	2-4
Unpacking	2-4
Initial Assembly	2-4
<i>Table 1 – Distance from Vaporizer</i>	2-4
<i>Figure 2 – Vaporizer Dimensions</i>	2-5
<i>Figure 3 – Installation – 40/40H, 60/60H, 80/40H, and 120/60H vaporizers</i>	2-6
Vapor Distribution Line	2-6
<i>Table 2 – Recommended Vapor Distribution Line Size</i>	2-6
Liquid Inlet	2-7
Vapor Bypass Line (Optional)	2-7
Burner Supply Line (Optional)	2-7
Liquid Pump (Optional)	2-8
Economy Installation (Optional)	2-8
<i>Figure 4 – Economy Option</i>	2-8
Contaminant Separator – Filtaire (Optional)	2-9
<i>Figure 5 – Filtaire Operation</i>	2-9
Installing Multiple Units in Parallel	2-10
<i>Figure 6 – Installing Multiple Units in Parallel</i>	2-10
<i>Figure 7 – Installing Multiple Units in Parallel, Oversized Manifolds</i>	2-10
Leak Test	2-10
Check Regulator Pressures	2-10

3.

Operation

Starting the Vaporizer	3-11
<i>Figure 8 – Thermostat Dial Positions</i>	3-12
<i>Figure 9 – Thermostat Dial – Run Position</i>	3-13
Automatic Re-Ignition Operation	3-13
Economy Operation	3-14

4. Maintenance

Service and Maintenance	4-16
<i>Table 3 – Items to be Serviced Monthly</i>	4-16
<i>Table 4 – Items to be Serviced Annually</i>	4-17
Adjusting the Regulator & Thermostat	4-18
<i>Figure 10 – Regulator and Thermostat Adjustment</i>	4-18

5. Troubleshooting

Pilot	5-20
Main Burner Will Not Ignite	5-20
If Vapor Pressure Drops	5-20
<i>Troubleshooting Tree #1: Pilot Will Not Light</i>	5-21
<i>Troubleshooting Tree #2: Pilot Lights But Will Not Hold</i>	5-22
<i>Troubleshooting Tree #3: Main Burner Will Not Light</i>	5-23
<i>Troubleshooting Tree #4: Vapor Service Pressure Drops</i>	5-24

Appendix A: Technical Information

<i>Figure 11 – 40/40H and 60/60H Vaporizer Replacement Parts</i>	A-28
<i>Figure 12 – 40/40H and 60/60H Vaporizers: Inlet Valve, Capacity Control Valve, Pilot and Burner Assemblies</i>	A-29
<i>Table 5 – 40/40H and 60/60H Vaporizer Parts List (See Figure 11 and 12)</i>	A-30
<i>Figure 13 – 80/40H and 120/60H Vaporizer Replacement Parts</i>	A-31
<i>Figure 14 – 80/40H and 120/60H Vaporizers: Inlet Valve, Capacity Control Valve, Pilot and Burner Assemblies</i>	A-32
<i>Table 6 – 80/40H and 120/60H Vaporizer Parts List (See Figure 13 and 14)</i>	A-33
<i>Figure 15 – Vaporizer Spares/Kit Parts</i>	A-34
<i>Figure 16 – Inlet Valve and Capacity Control Valve Close up</i>	A-34
<i>Table 7 – Repair Kits and Other Available Replacement Parts 40/40H & 60/60H</i>	A-37
<i>Table 8 – Repair Kits and Other Available Replacement Parts 40/40H Only</i>	A-38
<i>Table 9 – Repair Kits and Other Available Replacement Parts 60/60H Only</i>	A-40
<i>Table 10 – Repair Kits and Other Available Replacement Parts 80/40H & 120/60H</i>	A-42
<i>Table 11 – Repair Kits and Other Available Replacement Parts 80/40H</i>	A-43
<i>Table 12 – Repair Kits and Other Available Replacement Parts 120/60H</i>	A-44

This page left intentionally blank

Options

Auto Re-igniter

40/40H, 60/60H, 80/40H & 120/60H, Auto Re-igniter System 115/230 VAC 50/60Hz, Use P/N: 3-8683, Quantity 1 per unit

See Page 3-14 for Details

40/40H, 60/60H, 80/40H & 120/60H, Auto Re-igniter System 9VDC, Use P/N: 1501-4002, Quantity 1 per unit

See Page 3-14 for Details

Contaminant Separator / Filtaire

40/40H, 60/60H & 80/40H, Filtaire Model F4, Use P/N: 20536 or 20536-ASME, Quantity 1 per unit

120/60H, Filtaire Model F6 - ASME, Use P/N: 20540 or 20540-ASME, Quantity 1 per unit

See Page 2-9 for Details

Economy Kit

40/40H, 60/60H, 80/40H & 120/60H, Economy Option Kit P/N: 80793, Quantity 1 per unit,

See Page 2-8 and 3-14 for Details

Inlet and Outlet Hand Valves

40/40H, 60/60H, 80/40H & 120/60H, 3/4" Gas Cock, Use P/N: 50337, Quantity 2 per unit

Pipeaway Adapter

40/40H, 60/60H, 80/40H & 120/60H, Pipeaway Adapter 3/4", Use P/N: 1501-5016, Quantity 1 per unit

1st Stage Regulator

40/40H, 60/60H, 80/40H & 120/60H, 3/4" 5-20 PSIG, Use P/N: 37111, Quantity 1 per unit

Introduction

1

Description/Overview

Congratulations on your purchase of an Algas-SDI Direct Fired vaporizer. Algas-SDI is an ISO 9001 registered company and your new vaporizer was manufactured under strict accordance with ASME and UL requirements and carries the associated marks and the ASME "U" stamp.

A Direct Fired vaporizer, as the name implies, is one in which heat is furnished by an open flame directly applied to the heat exchange surface, which in turn contacts the LP Gas liquid that is to be vaporized. The Algas-SDI Direct Fired vaporizers consist of seven (7) main components:

- Liquid inlet valve & float assembly
- Liquid reservoir or heat exchanger
- Thermostat supply regulator
- Thermostat
- Burners
- Capacity control valve
- Relief valve

HOW THE VAPORIZER WORKS

When the shut-off valve in the liquid supply line is opened, liquid is forced into the heat exchanger by the pressure in the storage tank. As the liquid level rises, some of the liquid boils off until it matches the pressure coming from the tank.

The flow of liquid into the heat exchanger will stop when the rising liquid forces the float upward, closing the liquid inlet valve, or when the pressure in the heat exchanger is the same as the pressure coming from the storage tank.

When the burner(s) is lit, the heat will boil off the liquid in the heat exchanger. During periods of low or no demand, the pressure will build up to the storage tank pressure. Whenever pressure in the heat exchanger starts to increase above the tank pressure, the pressure differential will cause the LP gas to flow back through the inlet valve to the tank.

Due to the boiling action and the flow back to the tank, the liquid level in the exchanger will drop. When the liquid level drops, the temperature sensor will sense the warmer vapor and cycle off the main burner(s).

As the demand increases, the pressure in the heat exchanger will drop. As a result, liquid will flow into the exchanger, and the temperature sensor will sense the cool liquid, and cycle the main burner(s) on.

During continuous operation, the burner(s) will cycle on and off to maintain the required supply of vapor. As long as the rate of vaporization exceeds the demand, the exchanger will contain a very small amount of liquid. The only time the exchanger will contain a large amount of liquid is when the demand is equal to or above the capacity of the vaporizer.

Whenever the demand exceeds the capacity of the vaporizer, the capacity control valve is engaged, which limits the withdraw rate from the exchanger to the maximum capacity of the vaporizer.

Introduction

The capacity control valve is a spring loaded valve mounted on the outlet of the exchanger. Liquid LP gas is supplied to the top of the valve and vapor from the exchanger to the bottom of the valve. During normal operation, the valve is held open by the force of the spring.


When the liquid/vapor pressure differential exceeds the spring force, the liquid pressure will begin to close the valve. This restricts the flow out of the vaporizer. Any increase in demand will create greater pressure drop. In turn, the valve will further restrict the flow of vapor from the unit. This throttling action will cause the gas outlet pressure to drop, allowing the pressure in the heat exchanger to build back up and maintain proper gas supply to the vaporizer's burner(s) and keep the vaporizer in operation.

DIRECT FIRED SYSTEM BASIC FEATURES

The vaporizer consists of seven (7) main components:

- Liquid inlet valve & float assembly
- Liquid reservoir or heat exchanger
- Thermostat supply regulator
- Thermostat
- Burners
- Capacity control valve
- Relief valve

Figure 1 – Direct Fired Vaporizer - System Basic Features



DIRECT FIRED VAPORIZER SPECIFICATIONS:

BURNER INPUT: 40/40H, 80/40H	51,360 BTU's/hr per burner		
60/60H, 120/60H	77,040 BTU's/hr per burner		
GAS CONSUMPTION:	1000 BTU's per gallon of propane vaporized		
<u>TOTAL BURNER INPUT</u>			
40/40H:	51,360 BTU's/hr	BURNER GAS PRESSURE*:	14" W.C.
60/60H:	77,040 BTU's/hr	BURNER GAS PRESSURE*:	18" W.C.
80/40H:	102,720 BTU's/hr	BURNER GAS PRESSURE*:	14" W.C.
120/60H:	154,080 BTU's/hr	BURNER GAS PRESSURE*:	18" W.C.
PILOT BURNER: 2200 BTU's/hr			
NOMINAL OPERATING TEMPERATURE**: 140 to 160 °F			

* Burner Gas Pressure measured between burner regulator and thermostat.

** Operating Temperature depends on ambient temperature, thermostat settings, and operating pressures.

Installation

2

GENERAL

- Install the system so it complies with all governing codes and regulations.
- Make up all threaded pipe connections with a sealing compound that is approved and listed for LP gas service.
- All above ground lines should be adequately supported.
- Any underground piping should be properly protected against corrosion.
- Vapor outlet lines up to the first stage regulator should be sloped toward the vaporizer to allow condensation in the vapor line to flow back to the vaporizer.
- Clean all foreign material from all pipes prior to making final connections.
- Test all joints as specified in the applicable codes for leaks before placing the piping system in service.

Unpacking and Initial Assembly

UNPACKING

Upon receiving your new vaporizer inspect package for any damage that may have occurred during shipping. Then carefully open package and inspect unit for damage. Remove all plastic shipping material from the vaporizer.

INITIAL ASSEMBLY

Install the Flue cap(s) on the top of the unit with the supplied hardware. Install the vaporizer a minimum of 15 feet from the storage tank valves (see Table 1 below).

On a level, firm, non-combustible base, secure vaporizer through the four (4) ½ inch holes (see Figure 2).

The vaporizer should be adequately protected against damage by moving vehicles.


If the vaporizer is to be installed in any building or enclosure, a relief valve pipeaway and a regulator relief pipeaway must be installed. The relief valve and regulator relief must be able to relieve outside of any enclosure or building.

Table 1 – Distance from Vaporizer

Exposure	Minimum Distance From Vaporizer Required
Storage Tank	10 feet
Storage tank shutoff valves	15 feet
Point of transfer	15 feet
Nearest important building or group of buildings or line of adjoining property which maybe built upon (except buildings in which vaporizer is installed).	25 feet

Reference NFPA58



Figure 2 – Vaporizer Dimensions



Model	"A"	"B"	"C"
40/40H	35"	29"	20"
60/60H	44 1/4"	37 3/4"	28 3/4"
80/40H	35"	29"	20"
120/60H	44 1/4"	37 3/4"	28 3/4"

Installation

Figure 3 – Installation – 40/40H, 60/60H, 80/40H, and 120/60H vaporizers



CAUTION

The entire installation must be leak tested prior to operating the system.

NOTE

Do not connect this vaporizer to a storage tank that has been used in vapor withdrawal service until the tank has been emptied and all sediment and heavy ends have been cleaned from it.

VAPOR DISTRIBUTION LINE (see Figure 3)

The vapor distribution line should be adequately sized for the service.

Table 2 – Recommended Vapor Distribution Line Size

Gas Line Length Ft.	Up to 50	50-150	150-250
40/40H Vaporizers	1"	1-1/2"	2"
60/60H Vaporizers	1-1/4"	1-1/2"	2"
80/40H Vaporizers	1-1/4"	1-1/2"	2"
120/60H Vaporizers	1-1/2"	2"	2-1/2"

* Nominal Pipe Size

1. Install a UL listed shut-off valve with a Minimum 250psi gas pressure rating
2. Install a thermometer after the vaporizer shut-off valve.
3. Install the first stage regulator as close to the vaporizer as possible, but not further than 24" from the outlet of the vaporizer. The outlet pressure of the regulator should be set at 4 to 6 PSI lower than tank saturated vapor pressure at lowest expected temperature; this may require periodic adjustment.

4. The second stage (or low pressure) regulator should be installed as close to the consuming equipment as practical.
5. A line relief valve may be installed (optional) to protect the regulators from excessively high pressure. If a line relief valve is used, set the blow pressure at approximately 10 PSI above the first stage regulator delivery pressure.

LIQUID INLET



NOTE

Do not install a check valve in the supply line between the tank and the vaporizer. Liquid must be able to flow both ways in that line.

1. Install the 60-mesh 3/4" strainer that is supplied with the unit on the liquid inlet to the vaporizer.
2. Install a UL listed shut-off valve with a Minimum 250psi gas pressure rating
3. The liquid line from the storage tank to the vaporizer should be of sufficient size to supply the vaporizer at full capacity with a maximum pressure drop of less than the hydrostatic head pressure (see NFPA 54).
4. Connect the vaporizer to the storage tank.

VAPOR BYPASS LINE (OPTIONAL)(see Figure 3)

1. Install a primary (first stage) regulator at the vapor outlet on top of the storage tank. Set this regulator to deliver gas at a pressure of 2 to 4 psi below the setting of the vaporizer regulator. Then if the vaporizer is overloaded or its output pressure drops off, the regulator on top of the storage tank will automatically take over.
2. Run a line from the regulator and tie it into the vapor service line downstream from the vaporizer first stage regulator.

BURNER SUPPLY LINE (OPTIONAL)

The vaporizer burners are supplied with vapor from the outlet of the vaporizer where the least possibility of condensation will take place. In regions where there is a problem with a high content of heavy ends in the LP gas, a separate vapor supply line to the burner control on the vaporizer may be installed. If a separate burner supply line is used, the following is recommended:

1. Disconnect the 1/4" line at the burner regulator inlet.
2. Disconnect the 1/4" line at the tee on top of the heat exchanger and plug it with 1/4-NPT plug.
3. Install a first stage regulator as close to the tank vapor outlet as possible. A manual shut-off valve should be installed ahead of the regulator.
4. Connect the supply line from the first stage regulator to the burner regulator at the vaporizer. Make sure that the supply is sized properly to handle maximum input rating of the vaporizer burner(s). See Figure 1.
5. For the 40/40H and the 80/40H, adjust the Thermostat Supply Regulator at the vaporizer to 14" W.C. (with the burner off) and the burner pressure regulator at the thermostat to 9" W.C. (with the burner on). For the 60/60H and the 120/60H, adjust the Thermostat Supply Regulator at the vaporizer to 18" W.C. (with the burner off).

Installation


LIQUID PUMP (OPTIONAL)

The liquid pressure to the inlet of the vaporizer must be a minimum of 6PSI higher than desired discharge pressure. If tank pressure cannot meet this requirement, install a pump in the liquid line under the storage tank to maintain the minimum pressure.

ECONOMY INSTALLATION (OPTIONAL)

A vaporizer with economy operation draws vapor from tank as primary source and utilizes the vaporizer only when needed. The intent is to allow the most economical operation and eliminate energy waste. To accomplish this, install an Algas-SDI 40/40H, 60/60H, 80/40H, or 120/60H vaporizer, operating on demand, combined with a primary vapor bypass. To do this you will need an economy kit that consists of several valves and regulators.

Figure 4 – Economy Option



After installing the vaporizer, install and set the regulators from the economy kit as follows:

1. Install the (1) Primary Vapor Regulator in the vapor line at the tank and set at 10 psig. The regulator must be installed so that any gas condensing between the regulator and the tank can run back into the tank.
2. Install the (3) Vaporizer Regulator at the outlet of the vaporizer and set at 13 psig or approximately 3 psig higher than the (1) Primary Vapor Regulator.
3. Between the (3) Vaporizer Regulator and the vaporizer outlet install the (2) Economy Regulator in reverse direction such that the outlet side of the regulator faces the vaporizer. This regulator should be set at 30 psig or just high enough to allow enough pressure in the tank to supply the full flow through the (3) Vaporizer Regulator when needed.

CONTAMINANT SEPARATOR – FILTAIRE (OPTIONAL)

The **FILTAIRE** is a filtering device designed to trap heavy hydrocarbons commonly present in LPG gas vapor. It also traps other materials, which may be in the gas due to storage conditions and internal condition of the equipment.


Impurities are collected in the system and periodically removed through the system blow down drain. Residual heavy end hydrocarbons with boiling points higher than pure LPG are trapped by the filter and fall to the bottom for removal.

A complete **FILTAIRE** system consists of inlet and outlet connections, a blow-down drain (5), a pressure gauge (4), a vent which is normally plugged (6), and a bypass valve system for cleaning (1, 2, and 3). The bypass valves enable the system to continue operating when the **FILTAIRE** is removed for cleaning (see *Figure 5*).

At 20 psig, recommend using Algas-SDI **FILTAIRE** Model F4 ASDI PN: 20536 or 20536-ASME for Direct Fired Models 40/40H, 60/60H, and 80/40H. At 20 psig recommend using Algas-SDI **FILTAIRE** Model F6 ASDI PN: 20540 or 20540-ASME for Direct Fired Model 120/60H.

Note: Items 4,5 and 6 are included with **FILTAIRE** assemblies.

Figure 5 – Filtaire Operation




Installation

INSTALLING MULTIPLE UNITS IN PARALLEL


Piping should be equal distance on both inlet and outlet piping for balanced performance.

Figure 6 – Installing Multiple Units in Parallel



An oversized inlet and outlet manifold may be used to balance the flow.

Figure 7 – Installing Multiple Units in Parallel, Oversized Manifolds



LEAK TEST



CAUTION

The entire installation must be leak tested prior to operating the system.

1. Close outlet valve.
2. Slowly open inlet valve and allow pressure to equalize in the vaporizer.
3. Apply a liberal amount of soap/water solution to ALL pipe connections.
4. Check for any leaks by observing new bubble formation in the soap/water solution.
5. **Repair any leaks before continuing.**


CHECK REGULATOR PRESSURES

See Adjusting the Regulator and Thermostat page 4-18.

This page left intentionally blank

Starting the Vaporizer

1. Before starting the vaporizer, close the outlet valve in the vapor service line.
2. Fill the vaporizer with LP gas liquid by slowly opening the liquid supply line valve between the storage tank and the vaporizer. If this valve is opened too quickly, the excess flow valve in the tank may close. If this occurs, close the liquid supply line valve and allow the excess flow valve to equalize and re-open.
3. If the vaporizer is installed with a separate burner supply line not connected to the vaporizer (see page. 2-7), open the valve supplying gas to the Thermostat Supply Regulator.
4. Turn the gas control dial on the gas thermostat counter-clockwise to the "PILOT" position. Hold the button in while lighting the pilot burner. Continue to hold the button for 30 to 60 seconds and release. Pilot should remain lit.
5. Turn the gas control dial on the gas thermostat counter-clockwise to the "ON" position. The burner may come on at this point.




WARNING


If pilot light goes off after releasing dial, turn control dial to "OFF", wait 5 minutes and repeat step 4.

Figure 8 – Thermostat Dial Positions

Off




Pilot



6. Set the Temperature control dial so the outlet temperature is 15 °F over the highest ambient temperature during full capacity operation. If a pump is used, set the Temperature control dial so the outlet temperature is 15 °F over the saturation temperature of the LPG during full capacity operation.
7. Allow the burner(s) to heat the vaporizer until the main burner cycles off.
8. Make sure all valves on consuming equipment are closed and open the valve in the vapor distribution line. Open all consuming equipment valves.
9. If the vaporizer is not going to be used for a long period of time, it should be bled down by closing the manual valve in the liquid outlet connection at the tank and allowing the consuming equipment to use all the liquid from the vaporizer. When the vaporizer is empty (this will be indicated by a loss of vapor service pressure), turn the control dial on the thermostat to **OFF** and close the vapor service valve.

Figure 9 – Thermostat Dial – Run Position



AUTOMATIC RE-IGNITION OPERATION

Lighting or re-lighting of the pilot flame is accomplished by a spark across a gap of approximately 5/32" from the electrode tip to the grounded surface of the pilot burner or to the thermocouple tip. When the flame is established, the pilot flame conducts a current to the grounded pilot burner and a solid state switch in the unit turns off the spark. If the pilot flame is extinguished, current to ground is interrupted and the solid state switch turns on the spark, which sparks at a nominal timing of 100 times per minute, re-lighting the pilot flame well before the thermocouple cools enough to drop out the thermostat safety system.

ECONOMY OPERATION

During normal operation and while the tank pressure is above 30 psig the primary vapor regulator supplies vapor to the load. During this time the economy regulator on the discharge side of the vaporizer remains closed, until the tank pressure drops below 30 psig. Low ambient temperatures may cause this low pressure in the fall or winter or by excessive demand such that the natural vaporization cannot maintain the tank pressure. When the tank pressure drops below 30 psig, the economy regulator opens allowing flow through the vaporizer and subsequently the higher discharge pressure from the vaporizer regulator (3) overcomes the lower setting of the primary vapor regulator. This allows flow only through the vaporizer thus preventing the tank pressure from being drawn down.

This page left intentionally blank

Service and Maintenance

The vaporizers, just like any other LP gas equipment, should be maintained periodically. The following maintenance schedule may be used as a guideline. This maintenance schedule includes items that must be serviced, the type of service to perform, and the frequency of service. However, this is only a suggested schedule. The conditions in your area and quality of the LP gas liquid may dictate a more stringent maintenance, but whatever your schedule, remember that maintenance is of paramount importance for trouble free operation of the vaporizer. See *Appendix A* for recommended spare parts and repair kits for proper maintenance.

CAUTION



The equipment described in this manual is designed to operate with LP gas, a flammable fuel under pressure. The nature of the application involves inherent hazards that could result in injury. ONLY a trained and fully qualified person should service this equipment.

Table 3 – Items to be Serviced Monthly

Items to be Serviced Monthly	Service to Perform:
Strainer	Remove and clean screen. Replace as necessary. In some cases it may be necessary to use some type of cleaner to remove all contaminants.
Pilot Burner Assembly	Inspect pilot assembly. The flame should envelope 3/8" to 1/2" of the thermocouple tip.
Main Burner Assembly	Inspect for proper flame. Check that air supply openings are clear of debris, dirt or trash. If needed, clean each burner orifice.
Relief Valves	Check all relief valves on vaporizer, liquid and vapor lines for signs of corrosion in outlet. Check all rain caps. Replace if damaged or missing.
Enclosure	Check access door and inside enclosure for debris and combustible material. Check and, if needed, clean the inlet louvers and vent cap(s).

NOTE

Before replacing thermostat, be sure the thermocouple (read while hot) is delivering the proper voltage to the thermostat (13 to 30 millivolts).

Table 4 – Items to be Serviced Annually

Items to be Serviced Annually	Service to Perform:
Thermostat	Check the thermostat for proper operation (<i>see Start-up Procedure</i>). If the thermostat is not operating properly, it should be replaced (the thermostat cannot be serviced).
Thermocouple	The electrical output of the thermocouple should be checked with a millivolt meter. The thermocouple (when hot) output should be between 13 and 30 millivolts. A lower than 13 millivolt reading indicates the thermocouple should be replaced.
Liquid Inlet Valve	Remove plug from inlet valve and wipe away debris. Use kit P/N: 3-0016 to replace valve seat, spring and O-ring on plug.
Capacity Control Valve	Disassemble and clean the valve assembly inside of the body. Use kit P/N: 3-0017 to replace the spring and the O-rings on the piston and plug. Use powdered graphite as lubricant around top of the piston. Use grease as lubricant for the O-ring on the valve plug.
Heat Exchanger(s)	Check heat exchanger flue for holes or excessive scale. Remove obstructions and debris if needed. Check heat exchanger bottom head for pitting. Should pitting be in excess of 0.125", replace heat exchanger.
Main Burner Assembly	Inspect for proper flame. Check that air supply openings are clear of debris, dirt or trash. If needed, clean each burner orifice. All Direct Fired vaporizers built after October 2002 use #66 orifice burner tips.

CAUTION




1. *When servicing a component in the liquid or vapor line, BE SURE that the LP-gas supply is shut off to that component before it is removed or disassembled. The vaporizer must be completely blown down before performing service. Be sure that ALL sources of ignition are extinguished within 25 feet of the work area.*
2. *When flaring the contents of the vaporizer, be sure that the burners are on to prevent freezing during the flaring operation.*

ADJUSTING THE REGULATOR & THERMOSTAT

1. Close the supply valve to the Thermostat Supply Regulator and vent lines.
2. Using a 1/8" NPT barb fitting and hose, connect a 0-30" manometer (or similar pressure indicating device) to the pressure tap port at the bottom side of the thermostat between the main burner supply tube and the pilot supply tube. You will have to remove the existing 1/8" hex plug first.
3. Connect a 0-30" manometer (or similar pressure-indicating device) to the bottom of the drip leg. You will have to remove the 3/8" plug and drain the drip leg first.
4. Open the supply valve to the Thermostat Supply Regulator.
5. Set the thermostat temperature control knob to the last notch before the "HIGH" mark on the dial.
6. Establish pilot by turning "ON/PILOT/OFF" knob on top of the thermostat to "PILOT". Push down the "START" knob while igniting pilot (hold knob down for 30 - 60 seconds). After pilot is established, rotate the "ON/PILOT/OFF" knob to the "ON" position (See Figure 8). The main burner(s) should now engage.
7. With the main burner operating, check the Thermostat Supply Regulator and burner gas pressure using the manometer. For the 40/40H and 80/40H, the desired pressure is 14" W.C. for the Thermostat Supply Regulator with the burner off. For the 60/60H and the 120/60H, the desired pressure is 18" W.C. with the burner off. To adjust the Thermostat Supply Regulator pressure, remove the cap (See Figure 10) and turn the adjustment screw clockwise with a standard screwdriver to increase the pressure. To adjust the pressure, remove the green cap on the top of the "ON/PILOT/OFF" knob and turn the adjustment screw clockwise with a standard screwdriver to increase the pressure. Replace all caps when complete.
8. Close the supply valve to the Thermostat Supply Regulator and ***wait until the pilot and main burner have extinguished.*** Turn the "ON/PILOT/OFF" knob to the "OFF" position. Remove the manometer and fittings. ***Replace all plugs before proceeding.***

Figure 10 – Regulator and Thermostat Adjustment



This page intentionally left blank.

1. PILOT - TROUBLESHOOTING TREES #1 & #2


- The pilot flame is adjusted at the factory to provide a non-blowing blue flame. If the flame is not adequate or the pilot does not stay lit, check the pilot burner to see if it is clear of any obstructions.
- Flame should envelope 3/8" to 1/2" of the thermocouple tip. If the pilot flame is too low, the thermocouple will not generate sufficient voltage to hold the main burner's valve open. If the pilot flame is too small, clean the pilot burner orifice, or replace the pilot. The 40/40H and 60/60H vaporizers use #18 pilot orifices, while the 80/40H and 120/60H use #23 pilot orifices.


2. MAIN BURNER WILL NOT IGNITE - TROUBLESHOOTING TREE #3


- Check the pilot burner as per 1. above.
- Check burner regulator. Disconnect tube from outlet side of regulator and check output pressure.
- If pilot burner and burner regulator check out OK, the problem is in the thermostat. Replace thermostat (the main burner will not come on unless the temperature in the heat exchanger drops).


3. IF VAPOR PRESSURE DROPS - TROUBLESHOOTING TREE #4

- Check burner; check pilot as per 1. and 2. above.
- If vapor pressure drops, but main burner(s) is working, vapor demand exceeds vaporizer capacity.
- Check liquid excess flow valve and shut off valve; make sure they are open.
- Close liquid inlet valve upstream of strainer. Bleed down system and clean strainer filter.









This page intentionally left blank.


APPENDIX A

TECHNICAL INFORMATION

This page intentionally left blank.

Appendix A



Figure 11 – 40/40H and 60/60H Vaporizer Replacement Parts



40/40H & 60/60H PARTS LIST

Note: 40/40H shown.

Figure 12 – 40/40H and 60/60H Vaporizers: Inlet Valve, Capacity Control Valve, Pilot and Burner Assemblies.




40/40H & 60/60H PARTS LIST

Appendix A

Table 5 – 40/40H and 60/60H Vaporizer Parts List (See Figure 11 and 12)

Item	Part Description	40/40H	60/60H
1	1/4" NPT Ball Valve	33819	
2	3/4" NPT Strainer	8138-132	
3	Baffle Plate	1502-5012	
4	Base Assembly	1502-4001	
5	Burner Manifold Assembly	1502-4006	
6	Burner Regulator	8151-102A	
7	Burner Regulator Supply Tube Kit	3-0776	
8	Burner Supply Tube Kit	41022	41034
9	Burner Tip	33581	
10	Cabinet Kit	41023	41029
11	Capacity Control Tube Kit	3-0778	
12	Capacity Control Valve	40C68	
13	Capacity Control Valve Piston	40C66	
14	Capacity Control Valve Repair Kit	3-0017	
15	Case Assembly Structure	1502-4003	1503-4001
16	Case Assembly with Door	41016	41043
17	CE Nameplate	451-512-01	1503-5005
18	Door Latch	37110	
19	Door Assembly	1502-4005	1503-4004
20	Drip Leg Kit	40403	
21	Heat Exchanger and Flue Assembly	451-304-01	1503-4003
22	Heat Exchanger Flue	451-506-01	1503-5006
23	Heat Exchanger Support Spacer	40C30	
24	Inlet Valve Plug	1501-5001	
25	Liquid Inlet Valve	3-4150	
26	Liquid Inlet Valve Cover	1501-5012	
27	Liquid Inlet Valve Orifice	3-4152	
28	Liquid Inlet Valve Repair Kit	3-0016	
29	Master Rebuild Kit	81111	41032
30	Repair Kit	3-0034	41030
31	Pilot Assembly Kit	81113	
32	Pilot Flame Guide	1502-5010	
33	Pilot Orifice and Thermocouple Repair Kit	3-0014	41031
34	Pilot Supply Tube Kit	41024	41033
35	Relief Valve	35009	
36	Starting Instruction Plate	1501-5004	
37	Thermocouple	37058	
38	Thermostat Control Valve	3-3540C	
39	Thermostat Cover	1501-5015-02	
40	Thermostat Heat Shield	40C42	
41	Thermostat Kit	41026-A	
42	Top Cover Assembly	451-405-01	
43	Tubing Replacement Kit	40401	41028
44	Vapor Outlet Reducer	3-0549	

Figure 13 – 80/40H and 120/60H Vaporizer Replacement Parts




80/40H & 120/60H PARTS LIST

Note: 80/40H shown.

Appendix A

Figure 14 – 80/40H and 120/60H Vaporizers: Inlet Valve, Capacity Control Valve, Pilot and Burner Assemblies.




80/40H & 120/60H PARTS LIST

Table 6 – 80/40H and 120/60H Vaporizer Parts List (See Figure 13 and 14)

Item	Part Description	80/40H	120/60H
1	1/4" NPT Ball Valve	33819	
2	3/4" NPT Strainer	8138-132	
3	Baffle Plate	1504-5014	
4	Base Assembly	1504-4001	
5	Burner Manifold Connector Kit	3-0783	
6	Burner Regulator	8151-102A	
7	Burner Regulator Supply Tube Kit	3-0779	41035
8	Burner Supply Tube Kit	41019	41037
9	Burner Tip	33581	
10	Cabinet Kit	81104	41039
11	Capacity Control Tube Kit	3-0778	
12	Capacity Control Valve	40C68	
13	Capacity Control Valve Piston	40C66	
14	Capacity Control Valve Repair Kit	3-0017	
15	Case Assembly Structure	1504-4002	1506-4003
16	Case Assembly with Door	41017	41044
17	CE Nameplate	452-509-01	1506-5010
18	Door Latch	37110	
19	Door Assembly	1504-4003	1506-4009
20	Drip Leg Kit	40403	
21	Flame Guide	1504-5013	
22	Flue, Left	452-505-01	1506-5005
23	Flue, Right	1504-5009	1506-5004
24	Heat Exchanger and Flue Assembly, Left	452-302-01	1506-3002
25	Heat Exchanger and Flue Assembly, Right	452-303-01	1506-3001
26	Heat Exchanger Connector Tube Kit	3-0792	
27	Heat Exchanger Support Spacer	40C30	
28	Inlet Valve Plug	1501-5001	
29	Left Burner Assembly	1504-4004	
30	Liquid Inlet Valve	3-4150	
31	Liquid Inlet Valve Cover	1501-5012	
32	Liquid Inlet Valve Orifice	3-4152	
33	Liquid Inlet Valve Repair Kit	3-0016	
34	Master Rebuild Kit	81112	41042
35	Repair Kit	3-0035	41040
36	Pilot Assembly Kit	41021	
37	Pilot Bracket	1504-5010	
38	Pilot Orifice and Thermocouple Repair Kit	3-0013	41041
39	Pilot Supply Tube Kit	40404	41036
40	Relief Valve	35009	
41	Right Burner Assembly	1504-4005	
42	Sleeve, 3/4"	3-1022	
43	Starting Instruction Plate	1501-5004	
44	Thermocouple	46-4	37050
45	Thermostat Control Valve	3-3540C	
46	Thermostat Cover	1501-5015-02	
47	Thermostat Heat Shield	40C42	
48	Thermostat Kit	41026-A	
49	Thermostat Supply Tube	1504-5005	
50	Top Cover Assembly	452-403-01	1506-4004
51	Tube Nut, 3/4"	7105X12	
52	Tubing Replacement Kit	40402	41038
53	Vapor Outlet Nipple	30063	

Appendix A

Figure 15 – Vaporizer Spares/Kit Parts



NOTE

Drawing shown for a 40/40H Vaporizer.

Figure 16 – Inlet Valve and Capacity Control Valve Close up




Figure 15 and Figure 16 Descriptions

- | | | |
|-----|---|----------------|
| 1. | Liquid Inlet Valve 40/40H, 60/60H, 80/40H & 120/60H | P/N: 3-4150 |
| | Repair Kit | P/N: 3-0016 |
| 1A. | Spring | P/N: 3-4172 |
| 1B. | Valve Seat Assembly | P/N: 3-4165 |
| 1C. | Gasket, Liquid Inlet Valve (Use with graphite powder) | P/N: 40C37 |
| 1D. | Gasket, Pin | P/N: 8135-101 |
| 1E. | O-Ring, Seal | P/N: 1501-5002 |
| 1F. | O-Ring, Seal | P/N: 9000-25 |
| 2. | Capacity Control Valve 40/40H, 60/60H, 80/40H & 120/60H | P/N: 40C68 |
| | Repair Kit | P/N: 3-0017 |
| 2A. | Spring | P/N: 40C69 |
| 2B. | O-Ring, Piston | P/N: 9000-19 |
| 2C. | O-Ring, Seal | P/N: 9000-25 |
| | *Additional part not included in capacity control valve repair kit: | |
| 2D. | Piston, Capacity Control | P/N: 40C66 |
| 3. | Pilot Assembly Kit: 40/40H & 60/60H | P/N: 81113 |
| | Pilot Assembly Kit 80/40H & 120/60H | P/N: 41021 |
| 4. | Drip Leg Kit | P/N: 40403 |
| 4A. | Valve, Ball 3/8" | P/N: 8127-111 |
| 4B. | Tee, Brass 3/8" | P/N: 3-1035 |
| 4C. | Plug, 3/8" | P/N: 8008-203 |
| 4D. | Nipple, Schedule 80 3/8" NPT | P/N: 30024 |
| 4E. | Thermostat Supply Tube | P/N: 1502-5004 |
| 4F. | Connector, 3/8" Tube x 3/8" MNPT | P/N: 34501 |
| 4G. | Connector, 3/8" Tube x 1/2" MNPT | P/N: 3-1042 |
| 4H. | Connector, 3/8" Tube x 1/2" MNPT, Elbow | P/N: 34508 |
| 4I. | Thermostat Supply Tube | P/N: 1502-5005 |
| 4J. | Connector, 3/8" Tube x 3/8" MNPT, Elbow | P/N: 34504 |
| 5. | Tubing Kit, 40/40H | P/N: 40401 |
| | Tubing Kit, 60/60H | P/N: 41028 |
| | Tubing Kit, 80/40H | P/N: 40402 |
| | Tubing Kit, 120/60H | P/N: 41038 |
| 5A. | Burner Regulator Supply Tube Kit 40/40H & 60/60H | P/N: 3-0776 |
| | Burner Regulator Supply Tube Kit 80/40H | P/N: 3-0779 |
| | Burner Regulator Supply Tube Kit 120/60H | P/N: 41035 |
| 5B. | Drip Leg Kit | P/N: 40403 |
| 5C. | Pilot Supply Tube Kit 40/40H | P/N: 41024 |
| | Pilot Supply Tube Kit 60/60H | P/N: 41033 |
| | Pilot Supply Tube Kit 80/40H | P/N: 40404 |
| | Pilot Supply Tube Kit 120/60H | P/N: 41036 |
| 5D. | Burner Supply Tube Kit 40/40H | P/N: 41022 |
| | Burner Supply Tube Kit 60/60H | P/N: 41034 |
| | Burner Supply Tube Kit 80/40H | P/N: 41019 |
| | Burner Supply Tube Kit 120/60H | P/N: 41037 |
| 5E. | Capacity Control Tube Kit | P/N: 3-0778 |

Appendix A

Figure 15 and Figure 16 Descriptions Continued

6.	Thermocouple And Pilot Orifice Kit 40/40H	P/N: 3-0014
	Thermocouple And Pilot Orifice Kit 60/60H	P/N: 41031
	Thermocouple And Pilot Orifice Kit 80/40H	P/N: 3-0013
	Thermocouple And Pilot Orifice Kit 60/60H & 120/60H	P/N: 41041
6A.	Orifice, Pilot Burner 40/40H	P/N: 46-6
	Orifice, Pilot Burner 60/60H, 80/40H & 120/60H	P/N: 37510
6B.	Thermocouple	P/N: 37058
7.	Regulator, Burner Supply	P/N: 8151-102A
8.	Thermostat Kit	P/N: 41026
9.	Burner Tip	P/N: 33581

Table 7 – Repair Kits and Other Available Replacement Parts 40/40H & 60/60H

40/40H & 60/60H		
3-0016: Liquid Inlet Valve Repair Kit		
Components	Description	Qty.
3-4165	Valve seat assembly	1
3-4172	Spring	1
40C37	Gasket, liquid inlet valve	1
8135-101	Gasket, pins	2
1501-5002	O-ring	1
9000-25	O-ring	1
3-0017: Capacity Control Valve Repair Kit		
Components	Description	Qty.
40C69	Spring	1
9000-19	O-ring	2
9000-25	O-ring	1
81113: Pilot Assembly Kit		
Components	Description	Qty.
33582	Pilot burner 40/40H & 60/60H	1
8034-103	Nut, Keps, #10-32	2
61059	Screw, Fill, Hd, Phillip, 10-32 X 1"	2
8031-107	Washer, Flat, #10-32	2

Appendix A

Table 8 – Repair Kits and Other Available Replacement Parts 40/40H Only (1 of 2)

40/40H Only		
41025: Drip Leg Kit		
Components	Description	Qty.
3-1035	3/8" brass tee	1
31080	Connector, male 3/8"T x 3/8" MNPT	3
3-1042	Connector, male 3/8"T x 1/2"P	1
30024	Nipple, 3/8"NPT x 2-1/2" long	1
8008-203	Plug, 3/8" 300#	1
8127-111	Valve, ball 3/8"	1
1502-5005	Thermostat supply tube 40/40H	1
1502-5004	Thermostat supply tube 40/40H	1
40401: Tubing Kit		
Components	Description	Qty.
3-0776	Burner Regulator Supply Tube Kit 40/40H & 60/60H	1
41024	Pilot Supply Tube Kit 40/40H	1
3-0778	Capacity Control Valve Tube Kit 40/40H & 60/60H	1
41025	Drip Leg Kit 40/40H	1
41022	Burner Supply Tube Kit 40/40H	1
41023: Cabinet Kit		
Components	Description	Qty.
1502-4005	Door assembly 40/40H	1
1502-4003	Case assembly structure 40/40H	1
1501-5012	Liquid inlet cover plate 40/40H, 60/60H, 80/40H & 120/60H	1
1502-5012	Plate baffle 40/40H & 60/60H	1
1502-4001	Base assembly 40/40H & 60/60H	1
451-405-01	Top assembly 40/40H & 60/60H	1
451-506-01	Flue 40/40H	1
1501-5015-02	Thermostat control valve cover 40/40H, 60/60H, 80/40H & 120/60H	1
3-0034: Repair Kit		
Components	Description	Qty.
3-0014	Repair kit, pilot & thermocouple 40/40H	1
3-0016	Repair kit, liquid inlet valve	1
3-0017	Repair kit, capacity control valve	1
81113	Pilot assembly kit 40/40H	1
41026	Thermostat/Thermowell kit	1

Table 8 – Repair Kits and Other Available Replacement Parts 40/40H Only (2 of 2)

40/40H Only		
3-0014: Thermocouple and Pilot Kit		
Components	Description	Qty.
46-6	Orifice pilot burner 40/40H & 60/60H	1
46-5	Thermocouple for 40/40H	1
81111: Master Rebuild Kit		
Components	Description	Qty.
3-0034	Repair kit 40/40H	1
33581	Burner tips	10
8122-176	Regulator, burner 40/40H	1

Appendix A

Table 9 – Repair Kits and Other Available Replacement Parts 60/60H Only (1 of 2)

60/60H Only		
40403: Drip Leg Kit		
Components	Description	Qty.
3-1035	3/8" brass tee	1
31080	Connector, male 3/8"T x 3/8" MNPT	1
31058	Connector, male 3/8"T x 3/8" MNPT elbow	1
3-1042	Connector, male 3/8"T x 1/2"P	2
30024	Nipple, 3/8"NPT x 2-1/2" long	1
8008-203	Plug, 3/8" 300#	1
8127-111	Valve, ball 3/8"	1
1504-5005	Thermostat supply tube 60/60H, 80/40H & 120/60H	1
1504-5006	Thermostat supply tube 60/60H, 80/40H & 120/60H	1
41028: Tubing Kit		
Components	Description	Qty.
3-0776	Burner Regulator Supply Tube Kit 40/40H & 60/60H	1
41033	Pilot Supply Tube Kit 60/60H	1
3-0778	Capacity Control Valve Tube Kit 40/40H & 60/60H	1
40403	Drip Leg Kit 60/60H, 80/40H & 120/60H	1
41034	Burner Supply Tube Kit 60/60H	1
41029: Cabinet Kit		
Components	Description	Qty.
1503-4004	Door assembly 60/60H	1
1503-4001	Case assembly structure 60/60H	1
1501-5012	Liquid inlet cover plate 40/40H, 60/60H, 80/40H & 120/60H	1
1502-5012	Plate baffle 40/40H & 60/60H	1
1502-4001	Base assembly 40/40H & 60/60H	1
451-405-01	Top assembly 40/40H & 60/60H	1
1503-5006	Flue 60/60H	1
1501-5015-02	Thermostat control valve cover 40/40H, 60/60H, 80/40H & 120/60H	1
41030: Repair Kit		
Components	Description	Qty.
41031	Repair kit, pilot & thermocouple 60/60H	1
3-0016	Repair kit, liquid inlet valve	1
3-0017	Repair kit, capacity control valve	1
81113	Pilot assembly kit 40/40H	1
41026	Thermostat/Thermowell kit	1

Table 9 – Repair Kits and Other Available Replacement Parts 60/60H Only (2 of 2)

60/60H Only		
41031: Thermocouple and Pilot Kit		
Components	Description	Qty.
46-6	Orifice pilot burner 40/40H & 60/60H	1
37050	Thermocouple for 60/60H & 120/60H	1
41032: Master Rebuild Kit		
Components	Description	Qty.
41030	Repair kit 60/60H	1
33581	Burner tips	10
8151-102A	Regulator burner 60/60H, 80/40H & 120/60H	1

Appendix A

Table 10 – Repair Kits and Other Available Replacement Parts 80/40H & 120/60H

80/40H & 120/60H		
3-0016: Liquid Inlet Valve Repair Kit		
Components	Description	Qty.
3-4165	Valve seat assembly	1
3-4172	Spring	1
40C37	Gasket, liquid inlet valve	1
8135-101	Gasket, pins	2
1501-5002	O-ring	1
9000-25	O-ring	1
3-0017: Capacity Control Valve Repair Kit		
Components	Description	Qty.
40C69	Spring	1
9000-19	O-ring	1
9000-25	O-ring	1
40403: Drip Leg Kit		
Components	Description	Qty.
3-1035	3/8" brass tee	1
31080	Connector, male 3/8"T x 3/8" MNPT	1
31058	Connector, male 3/8"T x 3/8" MNPT elbow	1
3-1042	Connector, male 3/8"T x 1/2"P	2
30024	Nipple, 3/8"NPT x 2-1/2" long	1
8008-203	Plug, 3/8" 300#	1
8127-111	Valve, ball 3/8"	1
1504-5005	Thermostat supply tube 60/60H, 80/40H & 120/60H	1
1504-5006	Thermostat supply tube 60/60H, 80/40H & 120/60H	1
41021: Pilot Assembly Kit		
Components	Description	Qty.
1504-5013	Flame guide 80/40H & 120/60H	1
1504-5010	Pilot support bracket 80/40H & 120/60H	1
3-0641	Pilot burner 80/40H & 120/60H	1
37510	Pilot orifice burner 80/40H & 120/60H	1
8021-691	Screw	2
8021-719	Screw	2
8034-111	Nut	2

Table 11 – Repair Kits and Other Available Replacement Parts 80/40H Only

80/40H Only		
40402: Tubing Kit		
Components	Description	Qty.
3-0779	Burner Regulator Supply Tube Kit 80/40H	1
40404	Pilot Supply Tube Kit 80/40H	1
3-0786	Capacity Control Valve Tube Kit 80/40H & 120/60H	1
40403	Drip Leg Kit 60/60H, 80/40H & 120/60H	1
41019	Burner Supply Tube Kit 80/40H	1
81104: Cabinet Kit		
Components	Description	Qty.
1501-5012	Liquid inlet cover plate 40/40H, 60/60H, 80/40H & 120/60H	1
1504-4002	Case assembly structure 80/40H	1
1504-4003	Door assembly 80/40H	1
1504-5014	Plate baffle 80/40H	1
1504-4001	Base assembly 80/40H & 120/60H	1
452-403-01	Top assembly 80/40H	1
452-505-01	Flue 80/40H, left hand	1
1504-5009	Flue 80/40H, right hand	1
1501-5015-02	Thermostat control valve cover 40/40H, 60/60H, 80/40H & 120/60H	1
3-0035: Repair Kit		
Components	Description	Qty.
3-0013	Repair kit, pilot & thermocouple 80/40H	1
3-0016	Repair kit, liquid inlet valve	1
3-0017	Repair kit, capacity control valve	1
41021	Pilot assembly kit, 80/40H	1
41026	Thermostat/Thermowell Kit	1
3-0013: Thermocouple and Pilot Orifice Kit		
Components	Description	Qty.
46-4	Thermocouple, 80/40H	1
37510	Orifice pilot burner 80/40H	1
81112: Master Rebuild Kit		
Components	Description	Qty.
3-0035	Repair kit 80/40H	1
33581	Burner tips	20
8151-102A	Regulator burner 60/60H, 80/40H & 120/60H	1

Appendix A

Table 12 – Repair Kits and Other Available Replacement Parts 120/60H Only

120/60H Only		
41038: Tubing Kit		
Components	Description	Qty.
41035	Burner Regulator Supply Tube Kit 120/60H	1
41036	Pilot Supply Tube Kit 120/60H	1
3-0778	Capacity Control Valve Tube Kit 40/40H, 60/60H & 120/60H	1
40403	Drip Leg Kit 60/60H, 80/40H & 120/60H	1
41037	Burner Supply Tube Kit 120/60H	1
41039: Cabinet Kit		
Components	Description	Qty.
1501-5012	Liquid inlet cover plate 40/40H, 60/60H, 80/40H & 120/60H	1
1506-4003	Case assembly structure 120/60H	1
1506-4009	Door assembly 120/60H	1
1504-5014	Plate baffle 80/40H & 120/60H	1
1504-4001	Base assembly 80/40H & 120/60H	1
1506-4004	Top assembly 120/60H	1
1506-5005	Flue 120/60H, left hand	1
1506-5004	Flue 120/60H, right hand	1
1501-5015-02	Thermostat control valve cover 40/40H, 60/60H, 80/40H & 120/60H	1
41040: Repair Kit		
Components	Description	Qty.
41041	Repair kit, pilot & thermocouple 120/60H	1
3-0016	Repair kit, liquid inlet valve	1
3-0017	Repair kit, capacity control valve	1
41021	Pilot assembly kit, 80/40H & 120/60H	1
41026	Thermostat/Thermowell Kit	1
41041: Thermocouple and Pilot Orifice Kit		
Components	Description	Qty.
37050	Thermocouple, 60/60H & 120/60H	1
37510	Orifice pilot burner 80/40H & 120/60H	1
41042: Master Rebuild Kit		
Components	Description	Qty.
41040	Repair kit 120/60H	1
33581	Burner tips	20
8151-102A	Regulator burner 60/60H, 80/40H & 120/60H	1